


WETWELL

THE WETWELL PORT CAN BE USED FOR MANY PURPOSES INCLUDING HOUSING A PUMP AND FLOATS. WHEN HOUSING A PUMP IN THE WETWELL BE SURE TO DESIGN THE SUMP DEEP ENOUGH WITH THE R-TANKS SO THAT THE INTAKE OF THE PUMP IS LEVEL TOO OR SLIGHTLY HIGHER THAN THE FLOWLINE OF THE MAIN PORTIN OF THE TANK. FOR EXAMPLE, IF YOUR INTAKE IS 3' ABOVE THE BOTTOM OF THE PUMP, YOU WOULD USE A DOUBLE STACK SUMP AREAS THAT IS 2.89' DEEP. THIS WILL ALLOW FOR DRAW DOWN OF THE ENTIRE SYSTEM AND PREVENT VOLUME LOSS..



INTERNAL SUMP WETWELL